DYNEX™

46" LCD TV

QUICK SETUP GUIDE

DX-46L262A12

Composite cable

Remote control and 2 AAA batteries



AC power cord

TV stand and 4 screws (M5, 8 mm)

WE ARE GOING GREEN!

A copy of your *User Guide* is not provided in the box but is available online. Go to www.dynexproducts.com, click **Support & Service**. Enter your model number in the **Search** field, then press **Enter**. Click **Support/Downloads**.

Front features



Installing the stand

1 Carefully place your TV screen face-down on a cushioned, clean surface to protect the screen from damages and scratches.

2 Align the stand to the TV and secure it to the stand column with the screws provided.



Installing a wall-mount bracket

1 Carefully place your TV screen face-down on a cushioned, clean surface to protect the screen from damages and scratches.

2 Remove the screws that secure the stand to the stand column, then remove the stand.

3 Remove the screws that secure the stand column, then remove the column.



4 Attach the wall-mount bracket to your TV using the mounting holes on the back of your TV. See the instructions that came with the wall-mount bracket for information about how to correctly hang your TV.

Warning

This apparatus is intended to be supported by a UL Listed wall mount bracket.

Identifying cables

Your TV has several connection types for connecting devices. For the best video quality, connect a device to the best available connection.

Connection type	Video quality	Cable connector
HDMI video/audio	Best	
OR		
Component video and analog audio	Better	
OR		
Composite video and analog audio	Good	

You can use an HDMI jack to connect a DVI device to your TV. You need to attach an HDMI-to-DVI adapter to the end of the HDMI cable that connects to the DVI device's jack.

Connecting a DVD or Blu-ray player, cable box, satellite receiver, or game station

Using HDMI (best)



Using component cables (better)



Note: The COMPONENT IN jacks share the audio jacks with the AV IN VIDEO jack. Cables are often color-coded to match color-coded jacks.

Using composite cables (good)



Note: The AV IN VIDEO jack shares the audio jacks with the COMPONENT IN jacks. Connect red to red, white to white, and green to yellow.

Connecting an antenna/cable wall jack



Connecting a Home Theater System



Connecting a home theater system with multiple devices



We recommend that you connect the AV receiver's **HDMI OUT** jack to your TV's **HDMI IN** jack.

Setting up and using your remote control

1 Press the release button on the back of the remote to remove the battery compartment cover.

2 Insert two AAA batteries into the battery compartment. Make sure that the + and – symbols on the batteries match the + and – symbols in the battery compartment.

3 Replace the cover.







Aspect ratio options



Normal:
Displays the original 4:3 aspect ratio with black bars vertical on the left and right hand side of the screen. If the original aspect ratio is 16:9, then the image displays in 16:9.

Zoom:
Expands the image to fill the screen. The top and bottom of the image may be cropped.

Wide:
Use this option to view content recorded in a 16:9 (wide-screen) aspect ratio.

Cinema:
Stretches the image at the edges, but keeps a clear image in the center.

Auto:
Automatically adjusts the image based on the screen size and the TV program.
Note: Auto is only available when Auto Zoom in the Channels menu is set to On.



Input
Opens the Input Source list.

Power
Turns your TV on or off.

Numbers
Enter channel numbers.

.
Enter a digital sub-channel number. (Example: 4.1)

RECALL
Returns to the previous channel.

INFO
Opens a TV status banner.

GUIDE
Displays the program guide.

ENTER
Confirms selections or changes.

Arrows
Navigates in on-screen menus.

MENU
Opens the on-screen menu.

EXIT
Closes the on-screen menu.

MUTE
Mutes the sound.

Channel
Changes the TV channels.

Volume
Changes the volume.

FAVORITE
Opens the Favorite Channel List.

Quick Launch Inputs
Selects another source connected to your TV.
Note: The VGA button has no function.

MTS/SAP
Cycles through mono, stereo, and secondary audio for analog programs.

ZOOM
Changes how the picture displays on the screen.

CH-LIST
Opens the channel list.

PICTURE
Selects the picture modes.

CCD
Turns closed captioning on or off.

SLEEP
Sets the sleep timer.

AUDIO
Selects the audio modes.

Programming your remote control

To program your universal remote control to work with your new Dynex TV, see the table for common codes. If you have problems programming your remote or need a different remote control code, visit http://www.dynexproducts.com/remotecodes for the latest remote control code information.

Universal remote TV codes

Universal remote controls				Cable/Satellite/Set-top box								
One for All	Philips	RCA	Sony	Cablevision	Charter	Comcast	Cox	DirectTV	Dish Network	Time Warner	TiVo	Verizon
0054	**0198, 0490**	**135**	**068, 069, 078, 096, 100, 164, 168, 229, 026**	**068, 069, 078, 096, 100, 164, 168, 229, 026**	**2002, 1204, 1423, 1517, 0171, 1963, 0463, 1463, 0842, 1326, 167, 415, 424, 450, 456, 461, 507, 523, 567, 577, 586**	**10171, 11204, 11326, 11463, 11517, 11641, 11780, 11785, 11892, 11963, 12002**	**1326, 1463**	**10171, 11204, 11326, 11517, 11564, 11641, 11963, 12002**	**720**	**400, 450, 461, 456, 10463, 1463, 0463**	**0091**	**0198, 0490**

Connecting power

Plug the AC power cord into the **AC IN** jack on the back of your TV, then plug the other end of the cord into a power outlet.



Turning on your TV for the first time

1 Connect the power cord to your TV and to a power outlet, then press ⏻ (power). The *Choose Your Menu Language* screen opens.

2 Press ▲ or ▼ to highlight a language, then press **ENTER**. The *Choose Your Time Setting* screen opens with Mode highlighted.

3 Press ◄ or ► to select **Auto** or **Manual**. If you select **Auto**, the date and time are set automatically from a digital TV signal. If you select **Manual**, you can manually set the date and time. Press **ENTER**. The *Choose Your Picture Mode* screen opens.

4 Press ▲ or ▼ to highlight **Home Mode** or **Retail Mode**, then press **ENTER**. If you select **Retail Mode**, a message asks you to confirm your selection. Select **Yes** or **No**. **Retail Mode** is not an energy-saving mode. The *Choose Your TV Source* screen opens.

5 Press ▲ or ▼ to highlight **Antenna**, **Cable**, or **Cable/Satellite box**. If you select **Antenna** or **Cable**, your TV scans for available channels. The scan may take several minutes. If you select **Cable/Satellite box**, your TV does not scan for channels.

6 To watch TV, press **INPUT**, then press ▲ or ▼ to select the video input source for your TV signal. For example, select **HDMI** if your TV is connected to a cable/satellite box using an HDMI cable or select **TV** if your TV is connected to an antenna or cable/satellite using a coaxial cable.

2

4

3



5

DYNEX™

One-year limited warranty

Visit www.dynexproducts.com for details.

Need additional help?

See your ***User Guide***! This comprehensive guide includes everything from basic how-to steps to more advanced features. Go to www.dynexproducts.com, click **Support & Service**. Enter your model number in the **Search** field, then press **Enter**. Click **Support/Downloads**.

We're here for you

www.dynexproducts.com
For customer service, call:
800-305-2204 (U.S./Canada markets)

Distributed by Best Buy Purchasing, LLC
7601 Penn Avenue South, Richfield, MN USA 55423-3645

© 2011 BBY Solutions, Inc., All Rights Reserved.
DYNEX is a trademark of BBY Solutions, Inc. Registered in some countries. All other products and brand names are trademarks of their respective owners.

ENGLISH 11-0941